




Spa



Correct Method to Detach Bracket

Please follow below picture to detach bracket in case you press it on panel before installation



How to Install as a recessed fitting

① Cut the hole, according to expected size and shape

Refer to each Panel instructions below to match the cut-size:
34008: φ55 - 100mm
34009: φ55 - 175mm

② Put the 2pcs x slidable springs into the bracket, slide the springs and adjust its position according to the size of hole

Slidable Spring

③ Insert the bracket with 2pcs springs into Ceiling

④ Choose exact CCT (WW-NW-CW), by pushing Switch at right place

3CCT Switch
SELECT WITH A FINGER (PIN TOOL PROVIDED)

⑤ Open the Cover of Junction Box . Use Electric tools and press the fast connected terminal, and insert L & N wire. Then Closed the Cover

⑥ Aim Panel Light with Bracket's two sides, push up. Installation finished

★ Self-Lock Inside

How to Install as a ceiling fitting

① Fix the Bracket onto Ceiling, with 2pcs Screws

② Choose exact CCT (WW-NW-CW), by pushing Switch at right place

3CCT Switch
SELECT WITH A FINGER (PIN TOOL PROVIDED)

③ Open the Cover of Junction Box . Use Electric tools and press the fast connected terminal, and insert L & N wire. Then Closed the Cover

④ Aim Panel Light with Bracket's two sides, push up. Installation finished

★ Self-Lock Inside

How to Uninstall?

Ⓐ Before uninstall, turn off the power

Ⓑ Pull-out the Panel light Slowly

How to Uninstall?

✗ Don't take out Panel light from any one side of the self-lock area

If you do like this, the lamp will be damaged

✗ Don't take out Panel light from any one side of the self-lock area

If you do like this, the lamp will be damaged

✓ Press one side of Panel Light frame

Please take time to read this leaflet carefully and retain it for future reference.